



**Preferred coverage to protect your new purchase.**

- 24/7 Emergency Roadside Assistance\*
- ASE-certified claims adjusters
- Approved claims paid in less than 5 business days (*after the work is complete*)
- PWI only works with select dealerships that are known for quality, dependable pre-owned vehicles
- Rideshare friendly

\*24/7 Emergency Roadside Assistance is not available in California

## **BROKEN DOWN OR NEED REPAIRS?**

### **Remember to call PWI first!**

You must contact PWI **BEFORE** any repairs are made. Remember, you cannot submit a claim after repairs have been made. We can help you find a reputable repair shop to minimize your out-of-pocket expense or to help you get Emergency Roadside Assistance, if available with your Plan.\*

#### **2 ways to submit a claim:**

1. Call **800-548-1121** and have your PWI Customer Card available, if possible.
2. Create or log in to your online PWI account at [preferredwarranties.com](https://www.preferredwarranties.com) to submit your claim online directly to an adjuster.



*\*Ask your Dealer for a complete copy of the service contract terms and conditions.*

*\*\*This Contract is a service contract, and is not a warranty as that term is legally defined and commonly understood.*

*\*\*\*SIRIUSXM Offer Details, visit [siriusxm.com/PWI](https://www.siriusxm.com/PWI)*

© 2022 Preferred Warranties, Inc. All rights reserved.

PWI.206 7/22



## **VEHICLE PROTECTION PLANS**

Powertrain • Base • Plus

#### **To file a claim:**

800-548-1121

[preferredwarranties.com](https://www.preferredwarranties.com)

#### **For general inquiries email:**

[info@preferredwarranties.com](mailto:info@preferredwarranties.com)

Complimentary

**(((SiriusXM)))**



## Powertrain Plan

### Engine / Diesel Engine

All internal lubricated parts:

- Camshaft & bearings
- Connecting rods & bearings
- Crankshaft & bearings
- Exhaust valves
- Hydraulic & solid lifters
- Intake valves
- Main bearings
- Main engine oil pump, gears & pickup screen
- Pistons
- Piston rings & wrist pins
- Rocker arms & shafts
- Timing belt & gears
- Timing chain
- Valve push rods
- Valve springs & retainers

### Seals & Gaskets

All internal lubricated parts:

- Cylinder head gasket <sup>1</sup>
- Intake manifold gasket
- All other seals & gaskets only in conjunction with a covered repair

### Transmission / Automatic

All internal lubricated parts:

- Bands
- Bearings
- Bell housing <sup>1</sup>
- Bushings
- Friction & steel clutch plates
- Gears & shafts
- Governor
- Lock-up converter
- Pump
- Servo unit
- Shift solenoids
- Solenoid pack
- Steel drums
- Torque converter
- Transmission case <sup>1</sup>
- Valve body & plate

### Transmission / Manual

All internal lubricated parts:

- Bearings
- Bushings
- Gears & shafts
- Main drive gear
- Main shaft
- Shift forks
- Spacers
- Synchronizer drums
- Synchronizer
- Transmission case <sup>1</sup>

### Fluids & Filters / Diagnostics

- Any fluids & filters required for a covered repair (excluding A/C refrigerant)
- Reasonable diagnostic charges up to \$75

### Transfer Case <sup>1</sup>

All internal lubricated parts:

- Bearings
- Bushings
- Chains
- Gears
- Sleeves
- Sprockets
- Transfer case <sup>1</sup>

### Differential

All internal lubricated parts:

- Bearings
- Differential housing <sup>1</sup>
- Ring & pinion gears
- Spacers
- Spider gears & side gears

## Base Plan

Includes all Powertrain coverage and...

### Engine

- Flywheel/flex plate
- Water pump

### Fuel Delivery System

- Diesel fuel injectors
- Diesel fuel pumps
- Fluid pressure regulator
- Fuel injection control module
- Gas fuel injectors
- Gas fuel pump
- Metering valve/pressure regulator

### Suspension

- Ball joints
- Control arms
- Radius arms & bushings
- Coil & leaf spring
- Spindle / knuckle
- Stabilizer bar bushings & links
- Suspension air compressor

### Drive Axle

- CV joints
- Universal joints & wheel bearings

### Fluids & Filters / Diagnostics

- Freon including with a covered A/C repair

### Brakes

- Calipers
- Master cylinder
- Vacuum power assist booster
- Wheel cylinders

### Steering

All internal parts of:

- Steering gear box
- Steering rack & pinion unit

### Electrical

- Alternator
- Electric radiator cooling fan motor
- Power door lock actuator
- Power seat motors
- Power window motors
- Starter motor
- Starter solenoid
- Voltage regulator
- Windshield wiper motor (front & rear)

### Air Conditioning

- Accumulator
- Clutch bearing
- Compressor
- Compressor clutch
- Compressor seals
- Condenser
- Evaporator
- Expansion valve
- Idler pulley
- Receiver/drier

### Cooling System

- Radiator
- Thermostat
- Fan clutch
- Heater Core

### Rental

- Up to 3 days

## Plus Plan

Includes all Base coverage and...

### Engine

- Engine mounts
- Harmonic balancer & bolt
- Oil pan
- Timing & valve covers
- Vacuum pump

### Turbo (Supercharger) <sup>2</sup>

All internal parts:

- Bearings
- Supercharger housing
- Turbo charger housing
- Vanes
- Wastegate

### Drive Axle

- Axle shafts
- Center bearings
- Double offset joints
- Differential cover
- Drive shaft center bearings
- Propeller shaft
- Yokes
- 4WD locking hub

### Transmission

- Transmission mounts
- Transmission oil pan

### ABS

- Accumulator
- Electronic control processor
- Hydraulic pump
- Isolation dump valve
- Motor assembly
- Pressure modulator valve
- Wheel speed sensors

### Steering

- Electric power steering motor
- Main & intermediate steering shafts & couplings
- Power steering pump
- Steering column
- Steering shaft pivot joint

### Electrical / High Tech

- Convertible top power motor
- Electronic ignition module
- Idle air control motor & valve
- Ignition coil pack & distributor
- Ignition management controls:
  - AIT sensor
  - Camshaft & crank sensors
  - Coolant temperature sensor
  - Knock sensor
  - MAF sensor
  - MAP sensor
  - O2 sensor
  - Powertrain control module
  - TPS
  - Transmission input/output speed sensor
- Keyless entry transmitter & receiver
- Power mirror motor & motor switch
- Power seat switch
- Power window switch
- Windshield washer pumps (front & rear)

### Rental

- Up to 5 days

<sup>1</sup> Covered only if damaged by the failure of an internal lubricated part.

<sup>2</sup> Must be factory installed.