

Preowned Coverage Plan

Towing Reimbursement • Rental Car Reimbursement • Service Virtually Anywhere • Transferable • Travel Expenses • Choice of Deductibles • Payment Plan

Powertrain Protector Coverage



ENGINE:

Internally lubricated engine parts including, but not limited to:

- Pistons
- Piston rings
- Piston pins
- Crankshaft and main bearings
- Connecting rods and bearings
- Camshaft and bearings
- Timing gears
- Intake and exhaust valves
- Valve springs
- Valve guides
- Oil pump
- Push rods
- Rocker
- Rocker armshafts
- Hydraulic and solid lifters
- Distributor shaft and housing
- Balance shaft
- Accessory shaft



ENGINE (DIESEL):

The previously listed parts.



ENGINE (ROTARY):

- The previously listed parts plus:
- Rotor
 - Rotor seals
 - Rotor chamber
 - Eccentric shaft and bearings
 - All other internal parts of a rotary engine



FUEL PUMP (MECHANICAL OR ELECTRIC):

- Housing
- Diaphragms
- Springs
- Valves
- Actuating lever



TURBO/SUPER CHARGER:

Internal parts, vanes, shafts, bearings and housing if damage caused by a Breakdown of any of the previously listed covered components.



TRANSMISSION (AUTOMATIC):

- Internal parts including, but not limited to:
- Torque converter
 - Gears
 - Bearings
 - Bushings
 - Bands
 - Clutch plates
 - Friction and steel drums
 - Oil pumps
 - Servo units
 - Valve body and plate
 - Governor
 - Rings
 - Valves



TRANSMISSION (MANUAL):

- Transmission case if damaged by the failure of internally lubricated part.

Internal parts including, but not limited to:

- Bearings
- Bushings
- Shafts
- Spacers
- Main drive gear
- Main shaft
- Shift forks
- Synchronizing drum

- Gears
- All units within the overdrive housing



TRANSFER CASE (4X4):

Internal parts including, but not limited to:

- Bearings
- Bushings
- Sprockets
- Chains
- Sleeves
- Gears



DRIVE AXLES (FRONT & REAR):

Internal parts including, but not limited to:

- Ring and pinion gears
- Drive chain and gears
- Carrier bearings and bushings
- Pinion bearings
- Slide carrier bearings
- Carrier Assembly
- Thrust Washers
- Axles
- Axle bearings
- CV joints
- Internal transaxle seal
- Drive axle housing if damage is caused by failure of internally lubricated parts.

The differential housing is also covered if damage is caused by a Breakdown of any of the above covered components.



SEALS AND GASKETS:

Seals and gaskets are covered for components and/or parts listed with applicable surcharge.



Important notice: This is not a contract. This guide provides only a general summary of The Extended Coverage Program and its contents are limited by size. Protection provided will vary according to the plan selected. For detailed information, refer to the Terms and Conditions of Vehicle Service Contract.

Benefits

Roadside Assistance	Up to \$65 per incident
Trip Interruption	Food and lodging up to \$400 per contract.
Car Rental	Up to \$180 per contract conditions.
Deductible	No Deductible applies to the benefits.
Eligibility	Based on age and mileage, most vehicles qualify.
Terms	You can choose the number of months and miles that best fit your driving needs

Select Coverage

Includes all components listed under powertrain AND:



STEERING (MANUAL AND POWER):

- Steering gear box
- Pump assembly
- Rack and pinion
- Control valves
- Bearing and shafts
- Steering dampener
- Tilt wheel mechanism



ELECTRICAL:

- Alternator
- Starter motor
- Front and rear wiper motor
- Washer pump
- Horns
- Convertible top motor

Select Plus Coverage



ENHANCED ELECTRICAL:

- Voltage regulator
- Distributor
- Solenoids
- Manually operated switches
- Electronic Ignition module
- Power window motors
- Power seat motors
- Power door lock actuators



FUEL:

- Injection sensors and injectors




AIR CONDITIONING:

- Compressor
- Condenser
- Evaporator
- Expansion valve
- Receiver drier
- Blower motor
- Hot water valve



VARIABLE DAMPENING SUSPENSION:

- Electronic level control compressor including its sensor and limiter valve



Breakdown - Means the failure of a covered part under normal service. A covered part has failed when it can no longer perform the function for which it was designed solely because of its condition and not because of the action or inaction of any non-covered parts.

CAREGARD®

WARRANTY SERVICES, INC.

1900 Champagne Boulevard • Grapevine, TX 76051 • (800) 856.0990

Preowned Coverage Plan

Towing Reimbursement • Rental Car Reimbursement • Service Virtually Anywhere • Transferable • Travel Expenses • Choice of Deductibles • Payment Plan

Deluxe Coverage



ENGINE:

Internally lubricated engine parts including, but not limited to:

- Pistons
- Piston rings
- Piston pins
- Crankshaft and main bearings
- Connecting rods and bearings
- Camshaft and bearings
- Timing gears
- Intake and exhaust valves
- Valve springs
- Valve guides
- Oil pump
- Push rods
- Rocker
- Rocker armshafts
- Hydraulic and solid lifters
- Distributor shaft and housing
- Balance shaft
- Accessory shaft



ENGINE (DIESEL):

The previously listed parts.



ENGINE (ROTARY):

The previously listed parts plus:

- Rotor
- Rotor seals
- Rotor chamber
- Eccentric shaft and bearings
- All other internal parts of a rotary engine



FUEL PUMP (MECHANICAL OR ELECTRIC):

- Housing
- Diaphragms
- Springs
- Valves
- Actuating lever



TURBO/SUPER CHARGER:

Internal parts, vanes, shafts, bearings and housing if damage caused by a Breakdown of any of the previously listed covered components.



TRANSMISSION (AUTOMATIC):

Internal parts including, but not limited to:

- Torque converter
- Gears
- Bearings
- Bushings
- Bands
- Clutch plates
- Friction and steel drums
- Oil pumps
- Servo units
- Valve body and plate
- Governor
- Rings
- Valves



TRANSMISSION (MANUAL):

- Transmission case if damaged by the failure of internally lubricated part.

Internal parts including, but not limited to:

- Bearings
- Bushings
- Shafts
- Spacers
- Main drive gear
- Main shaft
- Shift forks
- Synchronizing drum

- Gears
- All units within the overdrive housing

Coverage does not include:

- Clutch assembly
- Clutch pressure plate
- Flywheel
- Pilot Bearing
- Throwout bearing



TRANSFER CASE (4X4):

Internal parts including, but not limited to:

- Bearings
- Bushings
- Sprockets
- Chains
- Sleeves
- Gears



DRIVE AXLES (FRONT & REAR):

Internal parts including, but not limited to:

- Ring and pinion gears
- Drive chain and gears
- Carrier bearings and bushings
- Pinion bearings
- Slide carrier bearings
- Carrier Assembly
- Thrust Washers
- Axles
- Axle bearings
- CV joints
- Internal transaxle seal
- Drive axle housing if damage is caused by failure of internally lubricated parts.

The differential housing is also covered if damage is caused by a Breakdown of any of the above covered components.



SEALS AND GASKETS:

Seals and gaskets are covered for components and/or parts listed with applicable surcharge.



AIR CONDITIONING:

Compressor

Internal Assembly including:

- Pistons
- Rods
- Valves
- Bearings
- Shafts
- Condenser
- Evaporator core
- Accumulator
- Expansion valve



FRONT SUSPENSION:

- Upper and lower control arms
- Control arm shafts and bushings
- Upper and lower ball joints
- Steering knuckles
- Stabilizer Shafts and bushings
- King pin and bushings
- Strut bar and bushings
- Spindles and spindle support
- Radius arm
- Radius arm bushings
- MacPherson struts and mounts
- Torsion Bars
- Wheel Bearings
- Torsion Mounts and Bushings
- Stabilizer Bar, Links, and Bushings Variable Dampening Suspension
- Compressor
- Control Module
- Dampening Actuator
- Solenoid
- Height Sensor
- Mode Selector Switch



BRAKES:

- Master cylinder
- Power assist boosters and valve
- Wheel cylinders
- Calipers
- Combination valve
- Steel lines and fittings



ANTILOCK BRAKE SYSTEM (ABS):

The non-ABS componenetes listed above plus the following:

- Booster and pump
- Master cylinder
- Control processor and solenoids
- Wheel speed sensors



SEALS AND GASKETS:

Seals and gaskets are covered for components and/or parts listed in Powertrain.



COOLING:

- Engine cooling fan and motor
- Fan clutch
- Belt tensioner
- Heater core
- Thermostat
- Blower motor
- Hot water valve
- Engine oil cooler
- Transmission cooler

Complete Coverage

Includes all components listed under Deluxe AND the following additional coverages:



AIR CONDITIONING:

- Low pressure lines
- Pressure cycling switches



AUDIO (FACTORY INSTALLED):

- Brackets, cables and wiring
- Cassette player
- Controls, rear seat
- Digital CD player
- Graphic equalizer
- Radio, AM/FM, Speakers



BRAKES:

Includes all components listed under Deluxe Plan



ELECTRICAL:

Includes all components listed under Deluxe AND the following additional coverages

- Charge and volt gauges
- Clock, electric
- Mirrors, motorized (electric only-not glass/housing breakage)
- Oil pressure gauge
- Temperature gauge
- Wiring harness

Important notice: This is not a contract. This guide provides only a general summary of The Extended Coverage Program and its contents are limited by size. Protection provided will vary according to the plan selected. For detailed information, refer to the Terms and Conditions of Vehicle Service Contract.



FRONT WHEEL DRIVE:

Includes all components listed under Deluxe



ENGINE:

Includes all components listed under Deluxe AND the following additional coverages

- Belt tensioners
- Motor mounts
- Pulleys
- Sensors



MISCELLANEOUS COMPONENTS:

- Accelerator linkage
- Convertible tilt mechanism
- Door latch assembly (front and rear)
- Hood latch and mechanism
- Seat track, front
- Speedometer casing and shaft
- Thermostat housing



REAR-FRONT WHEEL DRIVE:

Includes all components listed under Deluxe



SAFETY:

- Lock cylinder, door
- Lock lever assembly, door
- Lock level assembly, tailgate
- Lock lever retainers, clips and brackets



STEERING:

Includes all components listed under Deluxe



SUSPENSION:


Includes all components listed under Deluxe



TRANSMISSION:

Includes all components listed under Deluxe AND the following additional coverages

- Kickdown linkage
- Release hubs and bearings
- Transmission linkage
- Transmission mounts
- Vacuum module



Breakdown - Means the failure of a covered part under normal service. A covered part has failed when it can no longer perform the function for which it was designed solely because of its condition and not because of the action or inaction of any non-covered parts.

CAREGARD®

WARRANTY SERVICES, INC.

1900 Champagne Boulevard • Grapevine, TX 76051 • (800) 856.0990

